




Acer Aspire One ZG5 Battery Replacement

This guide will show you how to install a new battery.

Written By: Doug Gallatin



INTRODUCTION

There is a battery lock and a latch holding the battery in place.



PARTS:

- [Laptop Battery for Acer Aspire ZG5 Series](#) (1)
-

Step 1 — Battery



- Turn the netbook upside down with the battery at the top, away from you.

Step 2



- Unlock the battery by sliding the switch located near the left hinge to the left "unlocked" position.

Step 3



- Slide the latch located on the opposite hinge from the lock while pushing the battery up.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 02:05:37 AM.